



Pass Box

Pass Box is supporting equipment for clean room and workshop. It can be used for passing the wares between CR to CR or CR to non-clean room. It can decrease effectively the open times of CR's door and minimize the contamination extent of clean area.



Characteristic

- Body of the case is made of high-grade steel by folding and welding and its surface is treated with anti-corrosion and lacquered.
- With the interlock function, electrical interlock or mechanical interlock is optional.
- Showering and cleaning function are optional.
- UV light is optional.
- Window type, desk type and floor type are optional.
- Interphone is optional.
- Unpowered or powered roller convey function is optional.

Specifications

Model	APB-554I	HPB-554	SPB-557	CPB-557
Filter Efficiency	-	≥99.99%(@≥0.3μm)		
Cleanliness	-	ISO6(Class 1000)	-	ISO5(Class 100)
Air Velocity	-	≥0.3 m/s	>20 m/s (Nozzle)	≥0.3 m/s
Working Dim.	500X500X400 mm		500X500X700 mm	
Overall Dim.	685X590X470 mm		750X1300X770 mm	
Power Supply	AC220V, 1Φ, 50Hz			
Rated Power	60 W	180 W	650 W	550 W